



HYCO
Manufacturing Ltd

Firefly

Glueboard Uplighter

Model FF360G

Instruction Manual

Version 1.0 June 2009

HYCO FIREFLY GLUEBOARD UPLIGHTER

1. INTRODUCTION

Thank you for purchasing from our Firefly range of fly killers. The FF360G Glueboard Uplighter with its compact design is ideal for restaurants and other situations where a discreet wall position is required. Insects are caught silently and out of sight and the unit is easily maintained.

Do not proceed with installation or operation if there is sign of damage to the product. Please read and understand these instructions BEFORE first use.

If you have any queries regarding operation or installation please contact our technical department on 01977 517555.

2. IMPORTANT SAFETY POINTS



ALWAYS SWITCH OFF AND DISCONNECT POWER SUPPLY TO THE APPLIANCE BEFORE CLEANING.



DO NOT IMMERSE THE APPLIANCE IN WATER.



AVOID VERY DAMP CONDITIONS OR EXPLOSIVE ATMOSPHERES.



ENSURE HANDS ARE DRY BEFORE USING THE APPLIANCE.



ENSURE THE UNIT IS OUT OF REACH OF CHILDREN.



FOR INDOOR USE ONLY.



THE UNIT COMES PRE-WIRED WITH A BSI 363 UK PLUG. ALWAYS FIT THIS UNIT WITH A 3 AMP FUSE.



THE APPLIANCE MUST BE EARTHED.

3. INSTALLATION & POSITIONING

The unit should ideally be wall mounted around two metres off the ground. The unit will work best when located in the darkest part of the room so that the UV light does not compete with natural light in attracting insects. The unit should ideally be positioned so that the UV light can reach all parts of the room to be protected, but away from the most hygiene sensitive area.

3. INSTALLATION & POSITIONING (Continued)

Remove all packaging from the unit, find suitable location and mount on the wall using appropriate fixings. Fit the glueboard into position (see Glueboard Replacement part of Care and Maintenance section).

Connect the unit to mains power.

4. OPERATION

Flying insects are attracted to the ultra violet (UV) light generated by the special lamps supplied with the unit. The insects are then retained on the special adhesive board either for inspection or hygienic disposal.

- Press the switch to the **ON** position
- The UV lamps will illuminate

5. CARE AND MAINTENANCE

Cleaning – should be carried out regularly

- Ensure unit is switched off and disconnected from the power supply before cleaning
- Clean with a damp cloth
- Ensure that the unit is completely dry before switching back on

Lamp Replacement

- Replace lamps annually – do not wait for total failure as lamp ceases to be effective long before it fails.
- Turn off and disconnect power supply
- Lamps are held in place at one end via 4 pins
- Simply pull the lamp out of its holder and replace

Glueboard Replacement

- Turn off and disconnect power supply
- Remove the glueboard by sliding it out from the top of the unit
- Remove backing paper from the new board
- Gently slide into position ensuring the sticky side is facing the tubes

Starter Replacement

- Follow steps as above to remove glueboard
- Starters are removed by rotating anti-clockwise and pulling out of the unit
- Ensure correctly rated starters are used for the unit you have.

6. TECHNICAL SPECIFICATION

MODEL	DIMENSIONS (H X W X D)	COVERAGE (SQ. METRES)	LAMPS
FF360G	170 mm x 580 mm x 295 mm	80	2 x 18W
230-240VAC~50Hz			

7. GUARANTEE AND SERVICE POLICY

This product is guaranteed against faulty materials and manufacture for a period of one year from the date of purchase (excludes lamps). Hyco will in its sole discretion replace, repair or refund any faulty unit. Incorrect installation and failure to follow correct operating instructions are excluded. Consequential costs such as labour charges or damage to surroundings are expressly excluded.

H Y C O
Manufacturing Ltd

Hyco Manufacturing Ltd
California Drive
Whitwood
Castleford
West Yorkshire
WF10 5QH

Tel: 01977 517555 Fax: 01977 517666

Web: www.hyco.co.uk

E-mail: sales@hyco.co.uk