

HYCO
Manufacturing Ltd
HD15015

Hycos Wall Mounted hairdryer

Hycos Manufacturing Ltd
California Drive
Castleford
WF10 5QH

Tel 01977 517555
www.hycos.co.uk

version 1.1 Nov 2007

Instruction Manual

Hyco Manufacturing Ltd

Hyco Wall Mounted Hair Dryer

Technical specification

Model	HD15015
Power	1500W 230V 50Hz
IP Rating	IPX1
CE Approvals	EN-60335 CE LVD/EMC

General

Thank you for purchasing a product from Hyco Manufacturing Ltd.

Please read these guidelines before installation. If in any doubt, seek the advice of a qualified electrician or call our technical support line on 01977 517555.

Product Features

The HD15015 Wall Mounted Hair Dryer is suitable for hotels, gyms and similar applications.

Because all the electrical and heating components are located within the fixed wall mounted body of the product this unit is generally safer than a portable hair drying appliance.

⚠ It remains essential that the unit location is consistent with the product IP rating and that due regard is paid to the possibility of vandalism.

This model will start and stop automatically when the nozzle is removed from the base and will automatically switch off after approximately 18 minutes of continuous use. To reset the timer replace the nozzle.

The HD15015 model features a US/UK/European razor socket and electronic adjustable outlet air temperature control complete with an LCD display indicating remaining running time and the current temperature selected.

Installation

⚠ This model is rated IPX1. Site unit accordingly.

Use the enclosed template to drill 2 holes of 6mm diameter at the marked locations.

Fix the supplied plastic bracket to the top hole using the supplied screw and plug.

Open the access plate located on the base of the unit beneath the shaver socket using a cross head screwdriver.

Hook the top of the unit to the wall bracket and secure to the wall using the lower screw.

Electrical Connection

Connection must be in accordance with the latest Edition of the Wiring Regulations.

The unit is pre-wired with a UK plug, but note that for bathroom use a direct connection to a fused spur is required.

It is possible to connect a cable directly to the back of the unit so that there is no wiring visible to the user. There is a knockout disk next to the pre-wired flex exit that is designed to give cable access for this purpose.

If improved access to the terminal block or cable grip is required it is possible to remove the front cover by undoing the four recessed screws on the backplate. The terminal block should be accessible with the cover closed. If it is not, open the cover to re-position in a more convenient location.

Operation

Remove the nozzle from the base unit to start operation.

The green LCD will immediately light up and the dryer will blow warm air at the default temperature setting of about 60 degrees °C.

To adjust the temperature press the "+" or "-" buttons on front of the unit.

The current temperature is displayed, along with the remaining minutes before the unit automatically shuts down.

Clean product by wiping with a damp cloth. Do not use abrasive compounds or solvents.

Warranty

This product is guaranteed for a period of one year against faulty components or workmanship.

In the event of a warranty failure, Hyco will at its sole discretion repair or replace the unit.

Unless expressly agreed in writing, this guarantee does not provide for on-site labour costs. Consequential costs are excluded.

Technical Support

If you experience difficulties call our technical support on 01977 517555 between 8:30 and 5pm Monday to Friday.

Goods should not be returned without first contacting the manufacturer and obtaining a returns authorisation number.

Hyco Manufacturing Ltd

California Drive, Castleford WF10 5QH

Tel 01977 517555

www.hyco.co.uk